

# USER MANUAL



## TITANIA and TITANIAPLUS

Intrusion detection control unit with  
embedded OS

090020692



IMQ-SISTEMI DI SICUREZZA

IT08020000001624



## FOREWORD

### FOR INSTALLERS

Please follow carefully the specifications about electric and security systems realization further to the manufacturer's prescriptions indicated in the manual provided.

Provide the user the necessary indication for use and system's limitations, specifying that there exist precise specifications and different safety performance levels that should be proportioned to the user needs. Have the user read carefully the instructions provided in this document.

### FOR USERS

Carefully check the system functionality at regular intervals making sure all enabling and disabling operations were made correctly.

Have skilled personnel make the periodic system's maintenance. Contact the installer to verify correct system operation in case its conditions have changed (e.g.: variations in the areas to protect due to extension, change of the access modes, etc.)

.....

This device has been designed, assembled and tested with the maximum care, adopting control procedures in accordance with the laws in force. The full correspondence to the functional characteristics is given exclusively when it is used for the purpose it was projected for, which is as follows:

### Intrusion detection control unit with embedded OS

Any use other than the one mentioned above has not been forecast and therefore it is not possible to guarantee the correct functioning of the device. Similarly, any other use of this technical manual other than the one it has been compiled for - that is: to illustrate the devices technical features and operating mode - is expressly prohibited.

The manufacturing process is carefully controlled in order to prevent defaults and bad functioning. Nevertheless, an extremely low percentage of the components used is subjected to faults just as any other electronic or mechanic product.

As this item is meant to protect both property and people, we invite the user to proportion the level of protection that the system offers to the actual risk (also taking into account the possibility that the system was operated in a degraded manner because of faults and the like), as well reminding that there are precise laws for the design and assemblage of the systems destined to these kind of applications.

The system's operator is hereby advised to see regularly to the periodic maintenance of the system, at least in accordance with the provisions of current legislation, as well as to carry out checks on the correct running of said system on as regular a basis as the risk involved requires, with particular reference to the control unit, sensors, sounders, dialler(s) and any other device connected. The user must let the installer know how well the system seems to be operating, based on the results of periodic checks, without delay.

Design, installation and servicing of systems which include this product, should be made by skilled staff with the necessary knowledge to operate in safe conditions in order to prevent accidents. These systems' installation must be made in accordance with the laws in force. Some equipment's inner parts are connected to electric main and therefore electrocution may occur if servicing was made before switching off the main and emergency power. Some products incorporate rechargeable or non rechargeable batteries as emergency power supply. Their wrong connection may damage the product, properties and the operator's safety (burst and fire).

## DISPOSAL INSTRUCTIONS - USER INFORMATIONS



According to Directive 2012/19/EU on the Waste of Electric and Electronic Equipment (WEEE), it is here specified that this Electrical-Electromechanical Device started to be commercialized after 13<sup>th</sup> August 2005, and it shall be disposed of separately from ordinary waste products.

IT0802000001624



# 1. GENERALS

The TITANIA series intrusion detection control units have been especially created for high quality intrusion detection systems suitable for large banks, postal offices, company sites and multi-plant applications; they feature a high data processing power, paired with great usability and with up to 1024 inputs/outputs for the TITANIAPLUS model.

Up to 256 different users can access the system using proximity keys (using the I66 or I8 proximity readers) or 6-digits codes (using the system keypads, e.g. METIS, NIRVA, TATTILO, TATTILOPLUS, ANIMA or MIDAS).

The system can be divided in 8 separate areas with 4 partialization sectors each, each identified by a customized name.


Internal timers can activate or deactivate the various parts of the system at pre-defined times, following fixed, mobile and personalized holidays and allowing users to request overtimes.

Alarms will activate optical/acoustic self-powered outdoor sirens or self-protected indoor ones, directly connected to the control unit, while networking and dialler systems (on both landlines and GSM connections) transmit the alarm through primary and backup channels to control centres.

# 2. CONTROL DEVICES

## 2.1 Proximity key readers

The I66, I7 and I8 proximity key feature the following indications.






## 2.2 Keypads

Keypads feature an alphanumeric pad, a series of function buttons (labelled OK, STOP, arrow up and arrow down), a series of sectorization buttons (labelled S1 to S4), a display for the visualization of system messages, visualization LEDs and, in some models, an integrated proximity key reader.


Up to four other I66 or I7 proximity key readers can be connected directly to the keypad.

The following image shows the position of these elements on a NIRVA keypad:



The METIS series keypads have no integrated proximity reader and, since they have no backlit keys, they can not be used as main system keypads.

The LEDs in the S area of a METIS keypad (see below) behave like the backlights under the S1-S4 of a NIRVA keypad. The system LEDs, not available in other keypad models, are better detailed on the right.





## 3. USER MANAGEMENT

Two user levels exist:

- **User (Standard)**
- **Installer**

### 3.1 User

Users are enabled to arm and disarm a specific subset of the system (one or more sectors).

Users can also be enabled for max security arming.

They can modify their own access code, which is not available to anybody else.

#### 3.1.1 Administrator

Administrators are special users intended for some special circumstances, which are not detailed in this manual. It might happen that the installer mistakenly activates this mode: users 001 to 003 are marked as administrators and receive some of the features of the installer, including the possibility to deactivate the administrator mode again. Instructions on how to do so are included in the technical manual.

### 3.2 Installer

The installer can configure the whole system. While he can access the configuration via keypad, the configuration software provides for a quicker and finer programming.

By default, the installer can only access the control unit after a user authorizes the access. Once authorized, if the system administrator agrees, the installer can disable the need for this authorization procedure.

### 3.3 Fixed codes

Each user is paired to a 3-digits code from 001 to 256. The installer is assigned to the 000 code.

The default passwords are:

- **888888 for the installer;**
- **111111, 222222 and 333333 for the first three users;**
- **XXX000 for all other users, where XXX is their user number (e.g. user 074 has 074000).**

### 3.4 Summary table for operations and authorizations

Operations	User	Installer
Arming/disarming	Yes	Yes [browser only]
Max Security arming	Yes if enabled	Yes [browser only]
Zone exclusion	Yes if enabled	Yes
Output activation	No	Yes [browser only]
Password change	Own password only	Own password only [keypad] All [browser]
Change user properties	No	Yes
Reset user passwords	No	Yes
Add/delete users	No	Yes
Visualize user properties	No	Yes [browser only]
Visualize user passwords	No	No
Enable installer access	Yes	No
System lock	No	Yes



## 4. USER MANAGEMENT FROM THE KEYPAD

---

The installer can access the system and manage the users from the “Manage users” entry. Once a user code has been selected, the following options are available:

- **Access-enabled user:** enables or disables a user.
- **Change sectors:** allows for changing the sectors assigned to the user.
- **Disarming lock:** disables the system disarming for the user.
- **Access control:** enables the user to Access Control.
- **Do not send SMS:** disables SMS sending when the user arms/disarms.
- **EURO mode:** activates the EURO mode.
- **Max Security:** enables the max security arming.
- **Basic Maintenance:** enables access to the Basic Maintenance menu.
- **Reset password (user code):** resets the password to the default for that user (six times the last digit of the user code).

All users can change their own password by accessing the system and selecting the “Change Code” entry.




## 5. USER INTERFACE

### 5.1 Initial definitions


If the "Timeout" function is active, keypads used for programming automatically exit the configuration menu after 30 seconds from the last button pressed / command given (except where otherwise stated).

The "PROMPT" or "WELCOME MESSAGE" is the standard screen shown on the display when the control unit is idle and has no anomalies. The second row can be personalized with a message, usually the name of the installer or the name of the plant:



### 5.2 LED indications

Example using the NIRVA keypad.





## 6. OPERATIVITY

**Note:** the examples below use the NIRVA keypad. The buttons are shaped differently on different keypads.

### 6.1 General indications



SYSTEM ANOMALIES DISPLAY, e.g.




ZONES STATE DISPLAY, e.g.



ALARM MEMORY DISPLAY, e.g.



TAMPER MEMORY DISPLAY, e.g.



VISUALIZE THE SECTOR NAMES FOR THE CURRENTLY SELECTED AREA



LIT FOR ACTIVE AREAS VISUALIZATION (SYSTEM OR MULTI-AREA KEYPAD ONLY)




VISUALIZATION OF THE STATUS OF THE SELECTED AREA USING SECTOR KEYS S1-S2-S3-S4





## 6.2 User access

Despite there being 256 available users, **only the first 3 are active** after a factory reset. New users have to be activated by the installer, using the configuration software.




NOTE: BY DEFAULT, THE FIRST 3 USERS ARE ALLOWED TO BASIC MAINTENANCE OPERATIONS, INCLUDING GIVING THE INSTALLER PERMISSION TO ACCESS PROGRAMMING.

USER 001, 002 AND 003 HAVE THE 111111, 222222 AND 333333 DEFAULT USER CODES.

TO ACCESS THE BASIC MAINTENANCE MENU, PRESS THE FOLLOWING BUTTONS, IN SEQUENCE (EXAMPLE FOR USER 001):



User menus when the Basic Maintenance property is enabled.



NOTE:  
A USER WITH ACCESS TO THE BASIC MAINTENANCE MENU CAN ENABLE THE INSTALLER TO CONNECT USING BROWSERONE AND THE TITANIA MODULE.

BY DEFAULT, ONLY THE FIRST 3 USERS HAVE THE BASIC MAINTENANCE PROPERTY.

THE OTHER USERS CAN NOT SEE THE ENABLINGS AND MANAGE USERS MENUS.



### **6.3 System or area arming**

Perform a login (see “User access” on page 9) or keep the proximity key near to the reader for a few seconds. The arming procedure begins as soon as the sector lights start blinking fast.

**Not pressing any button for 5 s will confirm your choices and arm the chosen areas/sectors.**

You can now choose which sectors you want to arm. Sectors are assigned to the S1-S4 buttons. Press a sector button to include it (light ON, arm) or to exclude it (light OFF, do not arm). The LCD shows the name of the last sector pressed.

Keypads with backlit numeric keys can be multi-area keypads. Areas are assigned to the 1-8 buttons. If you are authorized to at least two of the areas available on a keypad, those area buttons will also light up. The first one will blink to indicate that this is the currently selected area, whose name appears on the display. To include/exclude a sector, select its area by pressing the corresponding area button, then proceed as above.

After confirming your choices by waiting for 5 s, the keys will blink slowly to mark the duration of the Exit Time. Leave the protected area. A confirmation signal sounds at the end of the Exit Time and all included sectors arm. The area and sector light remain lit to indicate the armed status.

#### **6.3.1 System or area arming with the automatic exclusion of zones**

If the installer flagged some zones for automatic exclusion, the user will be able to arm the system/area even if any of these zones is in anomaly condition. The affected zone will be excluded from the arming (therefore, it will not cause an alarm) as long as the system/area is armed.

#### **6.3.2 System or area arming with forced exclusion of zones**

If the installer activated the forced arming option, you will be informed about the presence of system/zone faults and anomalies.

After the area/sector selection (marked by fast blinking) ends, the LCD will show a sequence of all the zones that block the arming. You have 30 s to solve these alarms.

If you manage to, the display changes to “Arming ready”, press OK to arm the system/area.

If any alarms are still there, you can either press OK to force the arming (resulting in the automatic exclusion of the fault/anomaly zones), or wait for the Timeout (30 s) to cancel the arming procedure.

### **6.4 “MAX SECURITY” system arming**

Users with the “Max security” property can perform a “Max security” arming: only users with the “Max security” property will be able to disarm those sectors.

The process is the same as a normal arming (see “System or area arming” on page 10) but press # instead of OK after typing the password.

### **6.5 System or area disarming**

Perform a login (see “User access” on page 9) or keep the proximity key near to the reader for a few seconds: the S1-S4 backlights for the sectors assigned to the user shut down, and a confirmation signal will sound. Only users with the “Max security” property will be able to disarm areas armed in “Max security”.



## 6.6 Basic Maintenance access

For users authorized to the Basic Maintenance, use this variation of the login procedure to access the Basic Maintenance menu.



Use the arrow buttons to cycle through the menu entries, press OK to enter one.

### 6.6.1 User password change

Browse to “Change code”, press OK and type a new password.

In order to be sure that you typed the new password as intended, the system will ask you to repeat it.

Once you type in the password correctly, a confirmation signal will sound.

**Note:** in case you lost the password, use your proximity key to enter the Basic Maintenance menu and choose a new one:

- Get the key near to the reader.
- As soon as the S1-S4 backlights start blinking, press .

For more informations on the password change, see See “Change code” on page 13..

### 6.6.2 Visualize which zones are disabled (bypassed) / Enable/disable a zone

Browse to “Zone bypass” and press OK.

Type a zone number if you want to start with a specific one, or press OK to start from zone 1.

You are now inside a list of zones, positioned at the chosen one. Use the arrow keys to cycle through the list.

Press OK to bypass the currently shown zone or to include it again, then STOP to go back to the zone selection screen, saving the changes.

From here, you can type a new zone or press OK to go back to the zone list, or STOP to go back to the menu.

### 6.6.3 Read the event log

Browse to “Event log” and press OK.

Press # to visualize the timestamp of the event.

Use the arrow keys to cycle through events, STOP to go back to the description of the currently selected event.

### 6.6.4 Clock setup

Browse to “Clock setup” and press OK.

Set the current time:

- Use the arrow keys to cycle through the date and time fields.
- Type digits to change the highlighted value.

Press OK to save, STOP to exit without saving.

### 6.6.5 Dialler telephone book

Browse to “Phone numbers” and press OK.

You are now inside a list of 24 telephone numbers (No. 20 to 23 are to be used only for the GSM backup line); use the arrow keys to cycle through the list.

Press OK to modify the visualized number. Type the new number in, pressing the arrow buttons to move the cursor and OK to save (a confirmation signal will sound), STOP to go back to the list without saving.

Press STOP to go back to the menu.



### 6.6.6 Zones test

Browse to “Zones test” and press OK.

If no zone is set to “walk test”, a message will appear: press STOP. Otherwise, press OK again to start the test. Generate alarm conditions for each detector whose “walk test” checkbox in the configuration software has been flagged by the installer. Every time you successfully generate an alarm condition, a confirmation signal will sound.

The detectors that have not been successfully tested are listed in the LCD of the keypad. Use the arrow keys to browse the list.

Once you have verified that all the detectors function properly, or that some are faulty, press STOP twice to exit. A confirmation signal will sound.

**Note:** If the test is successful, a “Test done” message appears and the “Zones test OK” event is logged. If you exit the zones test menu while some zones have yet to be tested, the “Zones test failed” event is logged.

### 6.6.7 Output test

Browse to “Output test” and press OK.

The “ALARM relay +” output is displayed. Press OK to activate it for ~6 s (press STOP to shorten this time).

The next outputs are shown, “TAMPER relay +” and “SOUNDER relay +”. Press OK as above.

After testing those, the display shows “Output n.---”, select the output you want to test or press STOP to exit.

**Note:** testing the sirens might generate public nuisance. Additionally, if any output is connected to devices that signal the alarm to a control centre, warn them about the test.

### 6.6.8 Dialler test

Browse to “Dialler test” and press OK.

Press OK again: the control unit calls the first telephone number (a signal sounds and a message appears).

An error message appears if the dialler is not properly set or the first telephone number is empty.

Press STOP to exit.

**Note:** before testing the dialler, warn the owner of the called number.

**Note:** the test is not available unless at least one telephone number is saved to the control unit.

### 6.6.9 Battery test

Browse to “Dialler test” and press OK.

Press OK again to start the test. A progress bar will be displayed: [##### ].

Once the progress bar fills, wait at least 2 minutes and press OK to repeat the test, or press STOP to exit.

The results of the battery test can be seen in the Events Log (see “Read the event log” on page 11).

### 6.6.10 Weekly program

Browse to “weekly program” and press OK.

The display shows the date of tomorrow and the daily program currently set for tomorrow.

Press \* or # to cycle through the different daily programs (i.e. holiday; weekday; half holiday A; half holiday B: four different sets of activation and deactivation times that the installer memorized in the configuration software) and stop on the daily program you want to use tomorrow.

Press the arrow keys to visualize a different day of the next week (e.g. if today is Friday, from tomorrow to next Friday) and \*/# to change those daily programs as well.

Press OK to save the currently selected option for all seven days or STOP to exit without saving.



### 6.6.11 Change code

See “User password change” on page 11.

The “Manage Users” entry in the maintenance menu includes a reset password function that allows to reset the password to its default.

Example:

User 001, current password = 123456.

Enter the RESET PASSWORD menu and press OK:

User 001, current password = default password = 111111 (six times 1).

### 6.6.12 Granting access to the installer

Browse to “Enablings” and press OK.

The menu shows the current installer authorization (authorized or not), press OK again to change it.

A confirmation signal sounds and the menu closes automatically.

### 6.6.13 Overtime request

For this menu to be available, at least one arming program has to be active and the user has to be enabled to the areas and sectors associated to that program.

Browse to “Overtime” and press OK.

Use the arrow keys to cycle through the available programs and stop on the one you want to extend.

Press \* once to delay the arming by one hour. Any further pressure of \* delays the arming by a time set by the installer, up to a maximum delay that has also been set by the installer. Press # to reset the delay.

Press OK to save and STOP to exit.

**Note:** an error message appears if no time schedule...

- **is active**
- **is set to perform the arming event**
- **arms a sector authorized to this keypad and this user**
- **performs the arming event soon enough (as defined by the Max. Advance Time parameter set by the installer)**

### 6.6.14 GSM maintenance

Browse to “GSM” and press OK.

The first row shows the telephone company, the second row has a bar showing the strength of the signal:  
[##### ]

Press “Arrow up” to see the credit balance for prepaid cards. Pay-as-you-go cards show “not defined” instead. Press STOP to go back to the menu.

## 6.7 Simplified codes mode

If this mode is active, the control unit stops requiring the user number and the access is made by entering the 6-digits user code (password) only.

This means that no two passwords can be the same: when activating this mode, duplicated passwords are reset. Initially, only the installer and the first three users are activated, and their default code/password is 888888, 111111, 222222 and 333333 respectively.

**Warning:** This mode lowers the security level of the control unit.



## 7. SYSTEM TEST

---

The security system supervisor has to run periodical tests to ensure that the system works properly. The control unit has an internal reminder timer that can be set to 4 to 52 weeks but can not be deactivated. When the timer ends, the system anomaly LED ☹️activates. A user enabled to Basic Maintenance has to run the zones, outputs and dialler tests (see page 12). The control unit anomalies menu shows an anomaly for each test that has yet to be passed. Once all tests have been successfully run, the system anomaly LED turns off.

**Note:** the installer shall modify the '**System test**' timer only if the user requires it and only after he **detailed him the consequences of this operation** and after a formal assumption of responsibilities.

### 7.1 Automatic battery test

The control unit runs a battery test every 23 hours by applying a specific load to the battery for a duration of around 30 seconds. A failed test generates the appropriate anomalies. If the test would happen during a mains fault, it is postponed by 23 hours. When a low battery status is detected, the test is postponed to 30 minutes after the re-arm.



## 8. TABLE OF CONTENTS

1. GENERALS .....	3
2. CONTROL DEVICES .....	3
2.1. Proximity key readers .....	3
2.2. Keypads .....	4
3. USER MANAGEMENT .....	5
3.1. User .....	5
3.1.1. Administrator .....	5
3.2. Installer .....	5
3.3. Fixed codes .....	5
3.4. Summary table for operations and authorizations .....	5
4. user management from the keypad .....	6
5. USER INTERFACE .....	7
5.1. Initial definitions .....	7
5.2. LED indications .....	7
6. OPERATIVITY .....	8
6.1. General indications .....	8
6.2. User access .....	9
6.3. System or area arming .....	10
6.3.1. System or area arming with automatic exclusion of alarmed zones .....	10
6.3.2. System or area arming with forced exclusion of alarmed zones .....	10
6.4. "MAX SECURITY" system arming .....	10
6.5. System or area disarming .....	10
6.6. Basic Maintenance access .....	11
6.6.1. User password change .....	11
6.6.2. Visualize which zones are disabled (bypassed) / Enable/disable a zone .....	11
6.6.3. Read the event log .....	11
6.6.4. Clock setup .....	11
6.6.5. Dialler telephone book .....	11
6.6.6. Zones test .....	12
6.6.7. Output test .....	12
6.6.8. Dialler test .....	12
6.6.9. Battery test .....	12
6.6.10. Weekly program .....	12
6.6.11. Change code .....	13
6.6.12. Granting access to the installer .....	13
6.6.13. Overtime request .....	13
6.6.14. GSM maintenance .....	13
6.7. Simplified codes mode .....	13
7. SYSTEM TEST .....	14
7.1. Automatic battery test .....	14
8. TABLE OF CONTENTS .....	15

Intrusion detection control unit with embedded OS - TITANIA and TITANIAPLUS v.6 - USER MANUAL  
October 2017 edition

090020692

The information and product features herein are not binding and may be changed without prior notice.

**EL.MO. SpA** Via Pontarola, 70 - 35011 Campodarsego (PD) - Italy  
Tel. +390499203333 - Fax +390499200306 - Help desk +390499200426 - [www.elmospa.com](http://www.elmospa.com) - [international@elmospa.com](mailto:international@elmospa.com)