



# DEIMOS.R2RC

## Manuale d'istruzioni

---

RICEVENTE BICANALE - 433 MHz per codici fissi e rolling code

La ricevente DEIMOS.R2RC può apprendere codici fissi di qualsiasi brand, alla frequenza di 433.92 MHz.

### **Specifiche tecniche:**

- Alimentazione: 9-24 Vac/dc
- Numero di canali: 2
- Distanza massima di ricezione: 100 metri
- Frequenza di funzionamento: 433.92 MHz
- Tempo di lavoro modificabile

### **Programmazione:**

E' possibile associare i telecomandi in diverse modalità di funzionamento su entrambi i relè premendo "LEARN 1" per il primo relè e "LEARN 2" per il secondo relè:

#### **A uomo presente**

Per associare un nuovo codice, premi il pulsante di associazione sulla scheda. Il LED si accende una volta velocemente. Premi poi il pulsante del telecomando da associare. Il LED lampeggia 3 volte velocemente, a indicare il successo dell'operazione.

In questa modalità il relè rimarrà attivo finché il pulsante del telecomando sarà premuto.

#### **Bistabile**

Per associare un nuovo codice, premi due volte il pulsante di associazione sulla scheda. Il LED si accende due volte velocemente.

Premi poi il pulsante del telecomando da associare. Il LED lampeggia 3 volte velocemente, a indicare il successo dell'operazione

In questa modalità il relè rimane attivo fino ad un nuovo comando dallo stesso telecomando.



# DEIMOS.R2RC

## Instruction manual

---

### Two-channel receiver- 433 MHz rolling and fix code

The DEIMOS.R2RC receiver can learn fixed codes of any brand, at the frequency of 433.92 MHz.

#### Technical details:

- Power supply: 9-24 Vac/dc
- Number of channels: 2
- Max reception distance: 100 metri
- Operating frequency of transmitters: 433.92 MHz
- Editable working time

#### Programming:

It is possible to associate the remote controls in different operating modes on both relays, press "LEARN 1" for relays 1 or "LEARN 2" for relays 2:

#### Hold pressed

To associate a new code, press the association button on the card. The LED lights up once quickly. Then press the button on the remote control to be associated. The LED flashes 3 times quickly, indicating the success of the operation.

In this mode the relay will remain active as long as the remote control button is pressed.

#### ON/OFF

To bind a new code, double-click the bind button on the card. The LED lights up twice quickly.

Then press the button on the remote control to be associated. The LED flashes 3 times quickly, indicating the success of the operation.

In this mode the relay remains active until a new command is received from the same remote.