



PHOBOS.R1FC

Manuale d'istruzioni

RICEVENTE 433 MHz per codici fissi

La ricevente PHOBOS.R1FC può apprendere codici fissi di qualsiasi brand, alla frequenza di 433.92 MHz.

Specifiche tecniche:

- Alimentazione: 12-24 Vdc
- Numero di canali: 1
- Distanza massima di ricezione: 100 metri
- Frequenza di funzionamento: 433.92 MHz
- Numero di telecomandi associabili: 20
- Tempo di lavoro modificabile

Programmazione:

E' possibile associare i telecomandi in diverse modalità di funzionamento:

A uomo presente

Per associare un nuovo codice, premi il pulsante di associazione sulla scheda. Il LED si accende una volta velocemente. Premi poi il pulsante del telecomando da associare. Il LED lampeggia 3 volte velocemente, a indicare il successo dell'operazione.

In questa modalità il relè rimarrà attivo finché il pulsante del telecomando sarà premuto.

Bistabile

Per associare un nuovo codice, premi due volte il pulsante di associazione sulla scheda. Il LED si accende due volte velocemente.

Premi poi il pulsante del telecomando da associare. Il LED lampeggia 3 volte velocemente, a indicare il successo dell'operazione

In questa modalità il relè rimane attivo fino ad un nuovo comando dallo stesso telecomando.

The PHOBOS.R1FC receiver can learn fixed codes of any brand, at the frequency of 433.92 MHz.

Technical details:

- Power supply: 12-24 Vdc
- Number of channels: 1
- Max reception distance: 100 metri
- Operating frequency of transmitters: 433.92 MHz
- Number of associateable remote controls: 20
- Editable working time

Programming:

It is possible to associate the remote controls in different operating modes:

Hold pressed

To associate a new code, press the association button on the card. The LED lights up once quickly. Then press the button on the remote control to be associated. The LED flashes 3 times quickly, indicating the success of the operation.

In this mode the relay will remain active as long as the remote control button is pressed.

ON/OFF

To bind a new code, double-click the bind button on the card. The LED lights up twice quickly.

Then press the button on the remote control to be associated. The LED flashes 3 times quickly, indicating the success of the operation

In this mode the relay remains active until a new command is received from the same remote.



Delay di 5 secondi

Per associare un nuovo codice, premi quattro volte il pulsante di associazione sulla scheda. Il LED si accende tre volte velocemente.

Premi poi il pulsante del telecomando da associare. Il LED lampeggia 3 volte velocemente, a indicare il successo dell'operazione.

In questa modalità il relè rimane attivo per 5 secondi.

Delay di 10 secondi

Per associare un nuovo codice, premi cinque volte il pulsante di associazione sulla scheda. Il LED si accende tre volte velocemente.

Premi poi il pulsante del telecomando da associare. Il LED lampeggia 3 volte velocemente, a indicare il successo dell'operazione

In questa modalità il relè rimane attivo per 10 secondi

Delay di 15 secondi

Per associare un nuovo codice, premi sei volte il pulsante di associazione sulla scheda. Il LED si accende tre volte velocemente.

Premi poi il pulsante del telecomando da associare. Il LED lampeggia 3 volte velocemente, a indicare il successo dell'operazione

In questa modalità il relè rimane attivo per 15 secondi

Reset

Per eliminare tutti i radiocomandi salvati sulla ricevente è sufficiente premere il pulsante otto volte.

5 seconds delay

To bind a new code, press the bind button on the card four times. The LED lights up three times quickly.

Then press the button on the remote control to be associated. The LED flashes 3 times quickly, indicating the success of operation

In this mode the relay remains active for 5 seconds.

10 seconds delay

To bind a new code, press the bind button on the card five times. The LED lights up three times quickly.

Then press the button on the remote control to be associated. The LED flashes 3 times quickly, indicating the success of the operation., The remote is now allowed.

In this mode the relay remains active for 10 seconds

15 seconds delay

To bind a new code, pres the bind button on the card six times. The LED lights up three times quickly.

Then press the button on the remote control to be associated. The LED flashes 3 times quickly, indicating the success of the operation.

In this mode the relay remains active 15 seconds.

Reset

To delete all the remotes saved on the receiver, just press 8 times the button.