




ACV 20



8

027908 433893

DS11982_04/09/06/22

ADATTATORI PER COLONNINA E
PROTEZIONE ANTIVANDALO

ADAPTERS FOR POST AND
VANDAL-PROOF PROTECTION

ADAPTATEURS POUR COLONNE ET
PROTECTION ANTI-VANDALE

ADAPTER FÜR SÄULE UND
VANDALISMUS-SCHUTZVORRICHTUNG

ADAPTADORES PARA COLUMNA Y
PROTECCIÓN ANTIVANDALISMO

AANPASSTUKKEN VOOR KOLOM
EN VANDALISMEBEVEILIGING

ADAPTADORES PARA COLUMNA E
PROTEÇÃO ANTI-VANDALISMO


ΑΝΤΑΠΤΟΡΕΣ ΓΙΑ ΚΟΛΟΝΑΚΙ ΚΑΙ
ΑΝΤΙΒΑΝΔΑΛΙΣΤΙΚΗ ΠΡΟΣΤΑΣΙΑ

ADAPTERY DO KOLUMNY I
ZABEZPIECZENIE PRZED ZNISZCZENIEM

ПЕРЕХОДНИКИ ДЛЯ СТОЙКИ И
АНТИВАНДАЛЬНАЯ ЗАЩИТА

ADAPTÉRY PRO SLOUPEK A
OCHRANA PROTI VANDALISMU

UFKOLON ADAPTÖRLERİ VE
VANDALLIĞA KARŞI KORUMA



PHP ADA CC
PHP ADA BI
ACV 20

ISTRUZIONI DI INSTALLAZIONE
INSTALLATION MANUAL
INSTRUCTIONS D'INSTALLATION
MONTAGEANLEITUNG
INSTRUCCIONES DE INSTALACION
INSTALLATIEVOORSCHRIFTEN
INSTRUÇÕES DE INSTALAÇÃO
ΟΔΗΓΙΕΣ ΕΓΚΑΤΑΣΤΑΣΗΣ
INSTRUKCJE INSTALACJI
POKYN PRO INSTALACI
MONTAJ BILGILERİ

Attenzione! Leggere attentamente le "Avvertenze" all'interno! **Caution!** Read "Warnings" inside carefully! **Attention!** Veuillez lire attentivement les Avertissements qui se trouvent à l'intérieur! **Achtung!** Bitte lesen Sie aufmerksam die „Hinweise“ im Inneren! **Atención!** Leer atentamente las "Advertencias" en el interior! **Let op!** Lees de "Waarschuwingen" tigre aan de binnenkant zorgvuldig! **Atenção!** Ler atentamente as "Instruções" que se encontram no interior! **Προσοχή!** Διαβάστε με προσοχή τις "Προειδοποιήσεις" στο εσωτερικό! **Uwaga!** Należy uważnie przeczytać "Ostrzeżenia" w środku! **Внимание!** Внимательно прочтите находящиеся внутри "Инструкции"! **Dikkat!** İçinde bulunan "Uyarılar" dikkatle okuyunuz!



AZIENDA CON
SISTEMA DI GESTIONE
CERTIFICATO DA DNV GL
= ISO 9001 =
= ISO 14001 =

Bft

Bft
www.bft-automation.com
Bft Spa
Via Lago di Vico, 44 ITALY
36015 Schio (VI)
T +39 0445 69 65 11
F +39 0445 69 65 22


SPAIN
BFT GROUP ITALIBERICA DE
AUTOMATISMOS SL
Camí de Can Bassa, 6, 08401
Granollers, Barcelona, Spagna
FRANCE
AUTOMATISMES BFT FRANCE SAS
50 rue Jean Zay
69800 Saint-Priest, Francia
GERMANY
BFT ANTRIEBSSYSTEME GMBH
Faber-Castell-Straße 29, 90522
Oberasbach, Germania

UNITED KINGDOM
BFT AUTOMATION UK LTD
Unit C2-C3 The Embankment Business
Park, Vale Road Heaton Mersey Stockport
Cheshire SK4 3GL United Kingdom
BFT AUTOMATION (SOUTH) LTD
Enterprise House Murdock Road, Dorcan,
Swindon, England, SN3 5HY
PORTUGAL
BFT PORTUGAL SA
Urb. Pedrúlia lote 9 - Apartado 8123,
3025-248 Coimbra Portugal
POLAND
BFT POLSKA SP ZOO
Marecka 49, 05-220 Zielonka, Polonia




IRELAND
BFT AUTOMATION IRELAND
Unit D3 City Link Business Park, Old Naas
Road, Dublin
CROATIA
BFT ADRIA DOO
Obrovac 39, 51218, Dražice, Croatia
CZECH REPUBLIC
BFT CZ SRO
Ustecka 533/9, 184 00 Praha 8,
Czech
TURKEY
BFT OTOMASYON KAPI
Şerifali Mahallesi, no, 34775
Ümraniye/İstanbul, Turchia

U.S.A.
BFT AMERICAS INC.
1200 S.W. 35th Avenue Suite B Boynton
Beach FL 33426
AUSTRALIA
BFT AUTOMATION AUSTRALIA PTY
29 Bentley St, Wetherill Park NSW
2164, Australia
EMIRATES
BFT MIDDLEEAST FZCO
FZS2 A401 - PO BOX 262200, Jebel Ali Free
Zone South Zone 2, Dubai - United Arab
NEW ZEALAND
BFT AUTOMATION NEW ZEALAND
224/A Bush Road, Rosedale,
Auckland, New Zealand


PHP ADA CC



*
Non in dotazione / Not supplied
Ne sont pas fournis / Nicht im Lieferumfang
No asignadas en el equipamiento base
Niet meegeleverd / Não fornecidas
Δεν διατίθεται / Nie ma w zestawie
Отсутствует в комплектации
Není součástí balení
Tedarik dahilinde değil



PHP ADA BI



*
Non in dotazione / Not supplied
Ne sont pas fournis / Nicht im Lieferumfang
No asignadas en el equipamiento base
Niet meegeleverd / Não fornecidas
Δεν διατίθεται / Nie ma w zestawie
Отсутствует в комплектации
Není součástí balení
Tedarik dahilinde değil

