

SUN.MF – Trasmettitore e duplicatore multifrequenza**Descrizione**

Grazie alla sua ampia gamma di compatibilità, il trasmettitore **SUN.MF** è sicuramente il telecomando più duttile e universale presente ad oggi sul mercato.

I pulsanti del telecomando sono completamente indipendenti fra di loro, in questo modo è possibile memorizzare, in 4 diversi tasti, 4 diverse frequenze o 4 diversi brand, anche tutte diversi fra di loro.

Per ogni pulsante si può memorizzare:

- **Qualsiasi Brand;**
- **Qualsiasi frequenza**
- **Codici fissi;**
- **Rolling code.**



Frequenza	270 MHz - 900 MHz
Canali	4 canali indipendenti
Codici duplicabili	Codici fissi e rolling code
Alimentazione	1 batteria al litio 3 V – Tipo CR2032 (Inclusa)
Dimensioni	36 x 54 x 12 mm
Peso	30 g
Programmazione	Auto-apprendimento

Duplicazione

1. Posizionare il trasmettitore da clonare vicino al SUN.MF: circa a 3 cm di distanza tra uno e l'altro;
2. Premere e mantenere premuto il tasto 1 (in alto a sinistra) e, nel frattempo, premere per tre volte il tasto 2 (in alto a destra);
3. Rilasciare entrambi i bottoni e assicurarsi che il led del SUN.MF lampeggi lentamente;
4. Premere il pulsante del trasmettitore da copiare e attendere qualche secondo che il led del SUN.MF lampeggi più velocemente;
5. Mentre il led sta lampeggiando premere e mantenere premuto sul SUN.MF il pulsante sul quale si vuole memorizzare il codice appena trasmesso fino a quando il led non si spegne ad indicare il buon fine della procedura.

Scansiona il seguente codice QR per accedere alle istruzioni dettagliate e alla tabella di compatibilità:



Domotime srl

Via Monico, 9 25017 Lonato d/G (BS) – Italy –

Tel: +39 030 9913901 - Fax: +39 030 2070611

Skype: domotime - email: info@domotime.com - www.domotime.com

SUN.MF – Multi-frequency transmitter and duplicator

Description

Thanks to its wide compatibility range, the SUN.MF transmitter is certainly the most flexible and universal remote control available on the market today.

The keys of the remote control SUN.MF are completely independent from each other, in this way it is possible to memorize, in 4 different keys, 4 different frequencies or 4 different brands, even all different from each other.

For each key you can memorize:

- Any Brand;
- Any frequency as long as it is between 300 MHz and 900 MHz;
- Fixed code;
- Rolling code.



Frequency	270 MHz - 900 MHz
Channel	4 independent channels
Duplicable codes	Fix code and rolling code
Power supply	1 lithium battery 3 V – Type CR2032 (Included)
Dimensions	36 x 54 x 12 mm
Weight	30 g
Programming	Self-learning

Duplication

1. Place the transmitter to be cloned next to the SUN.MF: approximately 3 cm from one to the other;
2. Press and hold key 1 (upper left) and, in the meantime, press key 2 (upper right) three times;
3. Release both buttons and make sure that the SUN.MF LED flashes slowly;
4. Press the button of the transmitter to be copied and wait a few seconds for the SUN.MF led to flash faster;
5. While the led is flashing, press and hold on the SUN.MF the button on which you want to memorize the code just transmitted until the led goes out to indicate the successful completion of the procedure.

Scan the following QR code to access detailed instructions and compatibility table:



Domotime srl

Via Monico, 9 25017 Lonato d/G (BS) – Italy –

Tel: +39 030 9913901 - Fax: +39 030 2070611

Skype: domotime - email: info@domotime.com - www.domotime.com